

## Group of RDM Addressing

As below There is a group of RDM addressing process which is made of Swisson XMT-350. Please, follow the numbered drawings for RDM addressing of our products. Please check the link for more details click here [www.heraled.com/technic/1.mp4](http://www.heraled.com/technic/1.mp4)

**1**

Please open device with the button, choose RDM icon with the button, then select RDM icon by pressing the button

**2**

Connected products are scanned by device

**3**

Products are appeared on the RDM device screen. The products are chosen with and buttons, chosen product on display screen reveals itself with blinking light. (identify on) Select the button for chosen product addressing.

**4**

Please choose DMX Start Address on device screen by using and buttons and select it by the button

**5**

Please use the and buttons for addressing on this screen and select the buttons for confirmation. After the process is completed, press the button to go the product list screen.

**6**

As you choose different product on screen by using and buttons, previously chosen product will switch itself "identify off" mode in this case, chosen product begin to blink and previously chosen product will stop blinking.

## RDM Addressing Block Diagram

